

origin
DOORS AND WINDOWS

Magnetic keeps


90° Magnetic Keep

External Moving Corner Post Opening In
Internal Moving Corner Post Opening Out




1.

(Be aware that when installing the plate, there will be movement of the magnet on the plate as the doors are opened.)




2.







270° Magnetic Keep

External Moving Corner Post Opening Out
Internal Moving Corner Post Opening In




270° Magnetic Keep



3.



4.



origin
DOORS AND WINDOWS

Origin Global,
Sands 10 Industrial Estate, Hillbottom Road,
High Wycombe, Buckinghamshire, HP12 4HS

t 0808 168 5816
e info@origin-global.com
w www.origin-global.com